









# OWNER'S MANUAL

## PARTS LIST

This list contains replaceable parts used in your chainsaw. When ordering parts, be sure to provide the correct model and serial numbers (from the model plate), then the part number and description of the desired part.

### EL-7

| KEY NO.                            | PART NO.  | DESCRIPTION  | QTY.                 |  |
|------------------------------------|-----------|--|----------------------|--|
|                                    |           |  | 075762J<br>100089-07 | 098031J<br>099039J<br>100089-05<br>107714-02 |
| 1                                  | 097570-01 | Guide Bar, 14"   | 1                    | —  |
|                                    | 097572-01 | Guide Bar, 16"   | —                    | 1  |
| 2                                  | 091374-02 | Saw Chain  | 1                    | —  |
|                                    | 091375-02 | Saw Chain  | —                    | 1  |
| 3                                  | 100933-01 | Armature   | 1                    | 1  |
| 4                                  | 075676    | Sprocket Roller Bearing  | 1                    | 1  |
| 5                                  | 076744    | Hex-Head Bolt  | 2                    | 2  |
| 6                                  | 107512-01 | Oil Reservoir Cap  | 1                    | 1  |
| 7                                  | 099829-01 | Cord   | 1                    | 1  |
| 8                                  | 077399-02 | Side Cover, Black  | 1                    | 1  |
| 9                                  | 098042-01 | Field  | 1                    | 1  |
| 10                                 | 059606    | Drive Gear   | 1                    | 1  |
| 11                                 | 107713-01 | Internal Gear  | 1                    | 1  |
| 12                                 | 106810-01 | Sprocket Cover   | 1                    | 1  |
| 13                                 | 106809-01 | Front Hand Guard   | 1                    | 1  |
| 14                                 | 076053    | Motor Housing Assembly   | 1                    | 1  |
| 15                                 | 097034-02 | Housing Assembly   | 1                    | 1  |
| 16                                 | NPC-4C    | Hex Nut  | 2                    | 2  |
| 17                                 | 077115    | Adjusting Plate Assembly   | 1                    | 1  |
| 18                                 | 079086-02 | Oil Reservoir  | 1                    | 1  |
| 19                                 | 059046    | Pan-Head Tap Screw   | 6                    | 6  |
| 20A                                | 107708-01 | Pan-Head Shoulder Screw  | 1                    | 1  |
| 20B                                | 108120-01 | E-Ring   | 1                    | 1  |
| 21                                 | 076906    | Flat-Head Tap Screw  | 2                    | 2  |
| 22                                 | 097403-01 | Pan-Head Screw   | 1                    | 1  |
| 23                                 | 077143    | Sprocket Support   | 1                    | 1  |
| 24                                 | 077525S   | Lock-off Switch  | 1                    | 1  |
| 25                                 | 058059    | Thrust Washer  | 1                    | 1  |
| 26                                 | 079963-04 | Scabbard   | 1                    | 1  |
| 27                                 | 059045    | Pan Head Tap Screw   | 4                    | 4  |
| <b>PARTS AVAILABLE - NOT SHOWN</b> |           |  |                      |  |
|                                    | 079882-01 | Hardware Package<br>Includes: 2 - NPC-4C Nuts<br>2 - 076744 Bolts<br>1 - 097403-01 Screw | 1                    | 1  |

**IMPORTANT:** Your chainsaw is assembled with **EITHER** part **20A** **OR** part **20B** depending on your saw's design. See illustration on previous page to determine which saw design you have.